



USA Spare Part List					
Pos.	Part No.	Description	Pos.	Part No.	Description
1/1	604-001-010	Bottle	26	601-004-010	Hose Adapter Assembly
2	604-002-000	Piston Rod	26/1	601-004-011	Adapter, G1/8"
3	604-003-000	Spring	26/2	601-004-012	Cutting Ring
4	604-004-000	Countersunk Screw	26/3	601-004-013	Retaining Nut
5	604-005-000	Cylinder Cap	27	601-004-030	Coiled Hose
6	505-001-020	Spring	28	601-004-040	Hose Holder Spring
7	604-007-000	Piston	28/1	603-004-040	Hose Holder Spring
8	604-008-000	O-Ring	29	601-007-000	Flexi-Valve Assembly consisting 30-38
9	604-009-000	Pump Cylinder Assembly	30	601-007-010	Valve Handle
10	935-027-010	O-Ring	31	601-007-020	Valve Body
11	604-011-000	Cylinder Tube	32	505-003-014	Spring
12	604-012-000	Check Valve	33	601-007-040	Seat
13	604-013-000	Pressure Gauge	34	601-007-060	O-Ring, Viton
14	510-003-030	T-Connector	35	935-041-000	O-Ring, Viton
15/1	604-015-010	Bottle Cap	36	601-007-070	Seat Sleeve
16/1	604-016-010	O-Ring	37	601-007-080	Valve Cup
17	604-017-000	Hook	38	601-007-090	Trigger
18	601-018-000	Hook Ring	39	601-007-100	O-Ring, Viton
19	604-019-000	Pressure Release Valve	40	601-008-010	Extension , Spiral Wand
20	604-020-000	Supply Tube Assembly consisting 21,22	41	601-009-000	Aerosol Nozzle Set consisting 41/1,41/3,41/4
21	604-021-000	Tube Adapter	41/1	601-009-030	Aerosol Nozzle, White (optional)
22	604-022-000	Supply Tube	41/3	601-009-050	Aerosol Nozzle, Blue
23	604-023-000	Disc	41/4	601-009-070	Aerosol Nozzle, Red (optional)
24	505-002-020	Gasket	42/1	604-010-012	Extension, Crack-Crevise, 12cm
	604-035-000	Pump Service Kit, 8,10,12 16/1,20,24x3		601-023-200	Flexi-Valve Service Kit (34,35x2,39x3)
25	604-025-000	Hose Replacement Kit consisting 26/2x2,26/3x2,27			